



Assembly / 组装



Jet Fan 2:



* Do not install on the device's air outlet to avoid damage
勿装到机器出风口，避免损坏

* When the suction power decreases, please clean or replace the filter cartridge promptly
吸力降低时，请及时清理或更换滤芯

