


CHARGING CASE



Activate *
Multipoint



DE Ladebox ES Estuche de carga FR Étui de chargement IT Custodia di ricarica PT Caixa de carregamento SE Laddningsfodral JP 充電ケース
ZH 充电盒 TR Şarj kutusu BG кутията за зареждане CZ Nabíjecí pouzdro RO Carcasei de încărcare SK Správne Nabíjacie púzdro LV
Uzlādes futrāļa LT įkrovimo dėklas EE Laadimiskarbi PL Etui ładowujące


URBANISTA COPENHAGEN 2

—
QUICK START GUIDE
SCHNELLSTARTANLEITUNG
GUÍA DE INICIO RÁPIDO
GUIDE DE DÉMARRAGE RAPIDE
GUIDA RAPIDA
GUIA DE INÍCIO RÁPIDO
SNABBSTARTSGUIDE
クイックスタートガイド
快速入门指南
HIZLI BAŞLANGIÇ KILAVUZU
РЪКОВОДСТВО ЗА БЪРЗ СТАРТ
STRUČNÝ NÁVOD K POUŽITÍ
GHID DE ÎNȚIERE RAPIDĂ
SPRIEVODCA RÝCHLYM SPUSTENÍM
ĪSĀ LIETOŠANAS INSTRUKCIJA
GREITASIS NAUDOJIMO VADOVAS
KIIRKÄSIJUHEND
SKRÓCONA INSTRUKCJA OBSŁUGI




[Urbanista.com/manuals](https://urbanista.com/manuals)

POWER ON & CONNECT



DE Einschalten und anschließen ES Encender y conectar FR Allumer et connecter IT Accendi e connetti PT Encender y conectar SE Slå på och anslut JP 電源オン・接続 ZH 开机并连接 TR Gücü açın ve bağlanın BG Включете и свържете CZ Zapněte a připojte se RO Porniți și conectați SK Zapnite a pripojte sa LV Ieslēdziet un izveidojiet savienojumu LT Jjunkite ir prijunkite EE Lülitage sisse ja ühendage PL Włącz i połącz

TOUCH CONTROLS



DE Touchpanel ES Controles táctiles FR Commandes tactiles IT Controlli touch PT Controlos tácteis SE Touch-kontroller JP タッチコントロール ZH 触摸控制 TR Dokunmatik kontrollörler BG Сензорни управления CZ Dotykové ovládání RO Controale tactice SK Dotykové ovládanie LV Skārienvadība LT Jutikliniai valdikliai EE Puutejuhtimine PL Sterowanie dotykowe